



XX.Y®

HEADPHONES

www.xxy.eu

BLUEWAVE 20

User Guide

BLUEWAVE 20 BLUETOOTH HEADPHONES


USE

1. Compatible with mobile phones and other mobile devices (including iPhone and iPad) supporting Bluetooth function. Plays music, answers incoming calls wirelessly and outgoing calls.
2. Compatible with other devices with Bluetooth function (or Bluetooth USB adapter). Plays music or sounds from multimedia files wirelessly.

BATTERY CHARGE

The headphones are powered by a built-in lithium-ion battery. Low battery is signaled by a sound in the handset. To charge the battery, connect the headphones to the computer with a USB cable supplied. Using a car charger is not recommended during the first battery charge. The battery run time is up to 10 hours.

KEY FUNCTIONS



- S1: Multifunction key, On/Off, Answer call/End call, Reject incoming call, Call back
 S2: Previous: Play the previous track
 S3: Next: Play the next track,
 S4: Volume down
 S5: Volume up

PAIRING WITH BLUETOOTH SUPPORTING DEVICES

Pairing is linking Bluetooth capable devices to establish permanent and secure connection allowing fast data transfer between the devices without each time entering a password.

1. When the headset is turned off press and hold S1 button for about 6 seconds . You will hear the message "Power ON" and then "Pairing". Now the device is in pairing mode and ready to be detected by other Bluetooth capable devices.
2. Activate Bluetooth function of the mobile phone/tablet/computer you want to pair with Bluewave 20. Refer to the mobile phone/tablet/computer's manual if needed. The headphones will be detected as "Bluewave 20".
3. Select and confirm your Bluewave 20 out of those searched devices per the mobile phone/tablet/computer's manual. Access key: 0000
4. The pairing is complete. If the pairing process is unsuccessful, please repeat steps 1 to 4.

PAIRING WITH NFC TECHNOLOGY

Enable NFC on your phone / tablet. Bring them to the headphones Bluewave 20 in the space labeled logo NFC, and then confirm the pairing devices by selecting "Yes" on the screen of the smartphone/tablet/laptop. Repeat to disconnect the device.

SWITCH ON AND OFF

SWITCH ON

Press and hold S1 button for 3 seconds. The device and a previously paired mobile/tablet/computer (with activated Bluetooth function) will connect automatically.

SWITCH OFF

Press and hold S1 button for 5 second.

USE

After the headphones and a mobile phone/tablet/computer are paired, you can answer calls and talk (mobile only) and listen to music and sounds from the multimedia wirelessly.

REDIAL

In standby mode double press S1 key to redial the number you last called.

ANSWER THE CALL

Press S1 key shortly.

END THE CALL

Press S1 key shortly again to end your call.

REJECT THE CALL

Press and hold S1 button for 1 second.

DURING THE CALL

Volume adjustment: Increase or decrease the sound level by pressing S4 or S5 key respectively. Press and hold the keys for smooth volume adjustment.

Ending your call: press S1 key shortly to end call.

PLAYING MUSIC FROM YOUR MOBILE

Go to the previous track: press S2 key shortly

Go to the next track: press S3 key shortly

Pause/Restart: press S1 key shortly