



XX.Y®

HEADPHONES

www.xxy.eu

WINNER
BLUETOOTH EARPHONES

User guide

WINNER BLUETOOTH EARPHONES

USAGE

1. Supports mobile phones and other mobile devices with Bluetooth (including iOS devices). Wireless listening to music, answering and running incoming calls.
2. Supports other devices with Bluetooth (or Bluetooth adapter). Wireless listening to music or other multimedia sound.


CHARGING IN-BUILT BATTERY

Earphones powered by built-in lithium-ion battery. Use USB cable attached to the set, for charging.

1. Plug earphones to USB port with USB cable.
2. LED diode signals with red light, that the battery is being charged.
3. When the battery is fully charged LED diode turns off.

Charging time: 2 hours

BUTTONS' FUNCTIONS



- S1: On/Off/Answer the call/End the call
 S2: Volume up/Forward
 S3: Volume down/Backward
 S4: Microphone
 S5: LED diode
 S6: Micro USB slot for battery charging

EVAPORATING WITH BLUETOOTH DEVICES

Evaporating is a process which hooks up devices with Bluetooth. It creates the permanent and safe connection, enables quick work of devices without typing in a password at each use.

1. When earphones are turned off, hold S1 button for 6 seconds. LED diode starts blinking with red and blue light alternatively.
2. Search the Bluetooth device in your cell phone/tablet/PC, which you want to evaporate with Winner. When needed use the cell phone/tablet/PC's manual. Earphones are detected as „Winner“
3. In accordance with the cell phone/tablet/PC's manual, confirm the intent of connecting with Winner. Type the key: 0000 when needed.
4. Evaporating is finished. In case of unsuccessful attempt of connecting, repeat the action accordingly to 1-3 points.

SWITCH ON AND OFF

SWITCH ON

Press and hold S1 button for 3 seconds. LED diode starts blinking with blue light. The device automatically hooks up with previously evaporated cell phone/tablet/PC (with Bluetooth turned on).

SWITCH OFF

Press and hold S1 button for 4 seconds. LED diode will estinguish.

USAGE

After evaporating the earphones with cell phone/tablet/PC it is possible to answer and run the call (cell phone only) and wireless listening to music and other multimedia sound.

ANSWERING THE PHONE

Incomming calls signalled by mutting the music and double repeated sound signal. To answer the phone press quickly S1 button.

FINISHING THE PHONE CALL

Press quickly S1 button.

PLAYING MUSIC FROM THE CELL PHONE

Skip to the next song: Press quickly S2 button

Turn the volume up: Press and hold S2 button (reaching the maximum volume is signalled with the sound)

Skip to the previous song: Press quickly S3 button.

Turn the volume down: Press and hold S3 button (reaching the minimum volume is signalled with the sound)

Pause playing/Renew playing: Press quickly S1 button